

California Environmental Protection Agency



ARB Approved

Installation, Operation and Maintenance Manual
For The
Healy Phase II Enhanced Vapor Recovery System
Not Including ISD

Approved: April 8, 2005

NOTICE:

The ARB Approved Installation, Operation and Maintenance Manual for the Healy Phase II EVR System Not Including ISD describes the tools, method and skill levels required to install the **Healy Phase II EVR System Not Including ISD, ARB Executive Order VR-201-A.**

Unless specified otherwise, only skilled technicians that are trained, certified and licensed by Healy Systems, Inc. (i.e. Healy Certified Technicians) are able to perform installation, maintenance or repairs of components manufactured by Healy Systems, Inc. or warranty will be void.

It is the responsibility of each Healy Certified Technician to be familiar with the current requirements of state, federal and local codes for installation and repair of gasoline dispensing equipment.

It is also the responsibility of the Healy Certified Technician to be aware of all the necessary safety precautions and site safety requirements to assure a safe and trouble free installation.

Table of Contents

Healy Installation, Operation and Maintenance Manual

Component	Manufacturer/Model	Starts on Page
Scheduled Maintenance	Healy Systems Phase II EVR	1
Nozzle	Healy Model 900 EVR	6
Tank Pressure Management System	Healy Model 9961	16
Inverted Coaxial Hoses	Healy Model 75B Series	23
Hose Adaptors	Healy Model CX6 Series	26
Reconnectable Breakaway Coupling	Healy Model 8701VV	27
Flow Limiter	Healy Model 1301	30
Pressure/Vacuum Vent Valve	Husky Model 4885	31
Dispensers with Vacuum Pump	Gilbarco Encore 300 and 500 Series with Healy Model VP1000	32
	Gilbarco GasBoy 9800 Series with Healy Model VP 1000	56
	Wayne Harmony Series (Balance) with Healy Model VP 1000	76
	Wayne Harmony Series (Assist) with Healy Model VP 1000	95
	Wayne Ovation Series with Healy Model VP 1000	115
	Wayne Vista Series with Healy Model VP 1000	139